

Brand Name	Model
Apple	iPhone 2G
Apple	iPhone 3G
Apple	iPhone 3Gs
Apple	iPhone 4
Garmin asus	G60
HP	iPAD912
HTC	Dash 3G
HTC	Droid Eris
HTC	FUZE (TM) P4600
HTC	G1
HTC	HD2
HTC	Hero
HTC	HTC HD mini
HTC	HTC Tattoo
HTC	HTC Touch Diamond 2 T5353
HTC	HTC Wildfire A3333
HTC	MyTouch 3g
HTC	Nexus One
HTC	Pure
HTC	SHADOW
HTC	Shadow 2009
HTC	SMT 5800
HTC	Snap
HTC	Tilt 2
HTC	Touch Diamond
HTC	Touch Dual
HTC	Touch HD
HTC	Touch Pro
HTC	Touch Pro 2
LG	BL20v
LG	BL40
LG	CF360
LG	Chocolate Touch
LG	Dare VX9700
LG	enV3
LG	eXpo (GW820)
LG	GB250
LG	GC900
LG	GD 580 Lollipop
LG	GD310 Ice Cream 2
LG	GD510 Pop
LG	GD900
LG	Glance
LG	GM750
LG	GT505
LG	GT540
LG	GU230
LG	GU285
LG	GW520
LG	GW620
LG	GX200
LG	GX500

LG	INCITE
LG	KC910
LG	KM555
LG	KM900
LG	KP275
LG	KP500
LG	KS360
LG	Lotus LX600
LG	LX290
LG	LX370
LG	Neon (TM) GT365
LG	Rumor 2
LG	Scoop / AX-260
LG	Shine 2
LG	Shine II GD710 AT&T
LG	Shine KE970
LG	Versa
LG	Voyager VX10000
LG	VX5500
LG	VX8360
LG	VX8610
LG	Xenon (TM) GR500
LG	LX400
Moto	Backflip ME600
Moto	EM35
Moto	Z9N
Motorola	Cliq
Motorola	Clutch (i465)
Motorola	Droid
Motorola	E1
Motorola	E1070
Motorola	E398
Motorola	E8
Motorola	EM30
Motorola	i365
Motorola	i576
Motorola	i776
Motorola	I9
Motorola	K3
Motorola	Karma QA1
Motorola	MOTO (TM) Z9
Motorola	Q11
Motorola	Q9H
Motorola	RAZR V3
Motorola	RAZR V3xx Pink
Motorola	RAZR2 V9
Motorola	Rival
Motorola	SLVR L72
Motorola	U9
Motorola	V1100
Motorola	V360
Motorola	V365
Motorola	V3i

Motorola	V3x
Motorola	V500
Motorola	V550
Motorola	V551
Motorola	V6
Motorola	V750
Motorola	V80
Motorola	V860
Motorola	V9
Motorola	V950
Motorola	V9x
Motorola	VE20
Motorola	VE66
Motorola	VU30
Motorola	W510
Motorola	W755
Motorola	W766
Motorola	XT701 Milestone
Motorola	Z3
Motorola	Z6w
Motorola	ZN300
Motorola	ZN4
Motorola	ZN5
Nokia	2605
Nokia	2705
Nokia	2730
Nokia	2760
Nokia	3555
Nokia	3711
Nokia	5220
Nokia	5230
Nokia	5310
Nokia	5320
Nokia	5530
Nokia	5610
Nokia	5800
Nokia	6085
Nokia	6086
Nokia	6103
Nokia	6133
Nokia	6205
Nokia	6263
Nokia	6301
Nokia	6350
Nokia	6555
Nokia	6600
Nokia	6650
Nokia	6700
Nokia	6730
Nokia	7205
Nokia	7310
Nokia	7510
Nokia	7705

Nokia	8800
Nokia	2600C
Nokia	2680s
Nokia	2720 Fold
Nokia	2730 Classic
Nokia	3710 fold
Nokia	5130 XpressMusic
Nokia	5330TV
Nokia	5630Xpress
Nokia	6220c
Nokia	6303C
Nokia	6500 Slide
Nokia	6600i Slide
Nokia	6700 Clasic
Nokia	6700 slide
Nokia	7100 Supernova
Nokia	7210 Supernova
Nokia	7610s
Nokia	C5-00
Nokia	E52
Nokia	E63
Nokia	E66
Nokia	E71
Nokia	E71x
Nokia	E75
Nokia	E90
Nokia	Mural (6750)
Nokia	N73
Nokia	N78
Nokia	N79
Nokia	N85
Nokia	N86
Nokia	N96
Nokia	N97
Nokia	N97 Mini
Nokia	Surge (TM) 6790
Nokia	X3
Nokia	X6
Nokia	Z730C
Palm	Centro
Palm	Pixi
Palm	Pre
Palm	Treo 680
Palm	Treo 800w
Palm	Treo Pro
Pantech	Matrix Pro (TM)
PCD	Razzle TXT8060
RIM	BlackBerry 8120
RIM	Blackberry 8220
RIM	Blackberry 8350i
RIM	Blackberry 8530
Rim	Blackberry 8820
RIM	Blackberry 9300

RIM	Blackberry 9500
RIM	Blackberry 9530
RIM	Blackberry 9630
RIM	Blackberry 9700
Rim	Blackberry Bold 9000
RIM	BlackBerry Curve (8520)
Rim	Blackberry Curve 8310
Rim	Blackberry Curve 8320
Rim	Blackberry Curve 8900
Rim	Blackberry Pearl 8100
Rim	Blackberry Pearl 8110
RIM	BlackBerry Storm 9550 (Storm 2)
Samsung	A237
Samsung	a727
Samsung	A737
Samsung	a747
Samsung	A767 Propel
Samsung	A777
Samsung	A827
Samsung	B2100
Samsung	B7300
Samsung	Behold 2 (T939)
Samsung	Behold T919
Samsung	BlackJack (TM) II (i617)
Samsung	C3050
Samsung	C3110
Samsung	C5130
Samsung	C5212
Samsung	C5510
Samsung	D780
Samsung	D880
Samsung	D900i
Samsung	D988
Samsung	E390
Samsung	Eternity A867
Samsung	F110
Samsung	F330
Samsung	F480
Samsung	F490
Samsung	Flight
Samsung	Galaxy Spica GT-i5700
Samsung	Gravity 2 (T469)
Samsung	Gravity T459
Samsung	Highlight
Samsung	i200
Samsung	I450
Samsung	i520
Samsung	i640v
Samsung	i7500 Galaxy
Samsung	i780
Samsung	i8000 Omnia
Samsung	i8510
Samsung	i8910 HD

Samsung	i907 Epix
Samsung	i910
Samsung	Impression (A877)
Samsung	Instinct HD (M850)
Samsung	Instinct S30
Samsung	Intensity
Samsung	Intrepid (I350)
Samsung	J200
Samsung	J700
Samsung	J758
Samsung	J808
Samsung	Jack i637
Samsung	L708
Samsung	L760
Samsung	L770
Samsung	M220
Samsung	M310
Samsung	M320
Samsung	M330
Samsung	M5650
Samsung	M630
Samsung	M7600
Samsung	M8910
Samsung	Magnet A257
Samsung	Moment
Samsung	Mythic A897
Samsung	Pixon M8800
Samsung	Propel (TM) Pro i627
Samsung	Rant M540
Samsung	Reclaim (M560)
Samsung	Renown
Samsung	Rogue
Samsung	Rugby (A837)
Samsung	S3030 Tobi
Samsung	S3600H
Samsung	S3650 Corby
Samsung	S5230
Samsung	S5500
Samsung	S5550 Shark
Samsung	S5560
Samsung	S5600
Samsung	S5628 Monte
Samsung	S7070 Diva
Samsung	S7350
Samsung	S8000
Samsung	S8300
Samsung	Smooth
Samsung	Solstice (TM) (A887)
Samsung	Steel U900
Samsung	t229
Samsung	t239
Samsung	t349
Samsung	T559 Comeback

Samsung	T659
Samsung	t819
Samsung	T929 Memoir
Samsung	Trance
Samsung	u440
Samsung	U808
Samsung	A637
Samsung	A657
Samsung	Galaxy S i9000
Samsung	M520
Samsung	T339
Samsung	u430
Samsung	Wave S8500
Sanyo	Incognito (SCP-6760)
Sanyo	Katana Eclipse
Sanyo	Katana LX
Sanyo	PRO-700
Sanyo	SCP-2700
Sanyo	SCP-3810
Sony	Equinox
Sony Ericsson	C510 Black
Sony Ericsson	C901
Sony Ericsson	C902
Sony Ericsson	C905 Black
Sony Ericsson	F305
Sony Ericsson	G502
Sony Ericsson	G700
Sony Ericsson	G705
Sony Ericsson	G900
Sony Ericsson	J105i
Sony Ericsson	S302
Sony Ericsson	T650i
Sony Ericsson	T700
Sony Ericsson	T715
Sony Ericsson	TM506
Sony Ericsson	W300i
Sony Ericsson	W302
Sony Ericsson	W350 (Refurbished)
Sony Ericsson	W350a
Sony Ericsson	W518a
Sony Ericsson	W580i
Sony Ericsson	W595
Sony Ericsson	W660i
Sony Ericsson	W705
Sony Ericsson	W760a
Sony Ericsson	W810i
Sony Ericsson	W850i
Sony Ericsson	W960i
Sony Ericsson	W980
Sony Ericsson	Xperia X1
Sony Ericsson	Z310a
Sony Ericsson	Z750a
Sony Ericsson	Z770i

SonyEricsson	Aion U10
SonyEricsson	C903
SonyEricsson	Elm J10
SonyEricsson	F100
SonyEricsson	Hazel J20
SonyEricsson	K510a
SonyEricsson	K660i
SonyEricsson	Satio U1i
SonyEricsson	Vivaz U5
SonyEricsson	W395
SonyEricsson	W902
SonyEricsson	W995
SonyEricsson	X10
SonyEricsson	X10 mini
SonyEricsson	X10 mini pro
SonyEricsson	X2
SonyEricsson	Yari U100
SonyEricsson	Z550a
SonyEricsson	Z555
T-Mobile	T-Mobile Wing (S730)
UT Starcom	CDM8950
UT Starcom	GZ1 C711
Google	Google Nexus S
HTC	Evo 4G
HTC	HD7
HTC	Incredible
HTC	Ozone
HTC	Surround
HTC	Touch Pro2
LG	enV3 VX9200
LG	Vortex
Motorola	Backflip MB300
Motorola	Cliq MB200
Motorola	Droid 2
Motorola	Droid Pro
Motorola	Droid X
Nokia	5230 Nuron
Nokia	N8
Nokia	X6
Palm	Pixi Plus CDMA
Palm	Pre Plus CDMA
RIM	Blackberry Curve 3G 9300
RIM	Blackberry Curve 3G 9330
RIM	Blackberry Storm 2
RIM	BlackBerry Style (9670)
RIM	BlackBerry Torch (9800)
Samsung	Alias 2 U750
Samsung	Captivate (I897)
Samsung	Continuum (I400)
Samsung	Epic 4G (D700)
Samsung	Fascinate (I500)
Sony Ericsson	Aino
T-Mobile	G2

T-Mobile	MyTouch 3G Slide
T-Mobile	MyTouch 4G
Acer	Acer beTouch E210
Acer	acer E400
Acer	acer P400
Acer	DX650
Acer	E200
Acer	Liquid E
Acer	Liquid Mini (E310)
Acer	M900
Acer	S110
Acer	Smart handheld
Acer	Smart handheld
Acer	Smart handheld E100
Acer	Smart handheld E101
Alcatel	MISS SIXTY MSX10
Alcatel	OT-800/ OT-800A
Alcatel	OT-802/ OT-802A
Alcatel	OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D
Alcatel	OT-808/ OT-808A
Alcatel	OT-880/ OT-880A
Alcatel	OT-980/ OT-980A
Casio Hitachi	C721
Chi Mei	AQ4
Chi Mei	P300
FIH	FM600
FIH	N700
FIH	PDA Phone
FIH	test_RM-383
FIH	ViewPad7
Fujitsu	T-01C
Global High Tech	GHT Maestro
Hewlett-Packard	HSTNH-P21C
HTC	ADR6200VW
HTC	ADR6300
HTC	ADR6300
HTC	CDMA HTI11
HTC	CEDA100 Series
HTC	CEDA100 Series
HTC	CEDA100 Series (WM6.5)
HTC	EVO
HTC	HERO200
HTC	HTC Hero
HTC	HTC Snap
HTC	HTC Touch Diamond2
HTC	HTC Touch2
HTC	HTC Wildfire
HTC	Nexus One
HTC	PB00 Series
HTC	PB65 series
HTC	PB76100
HTC	PB81 Series
HTC	PB92100

HTC	PB92110
HTC	PB92110 series
HTC	PB99 (CDMA)
HTC	PB99 Android 2.2 series
HTC	PB99400
HTC	PC10100
HTC	PC10xxx
HTC	PC36100
HTC	PC36100
HTC	PC40100
HTC	PC402XX
HTC	PC57 Series
HTC	PC63xxx Android 2.2
HTC	PC70 series
HTC	PC92xxx
HTC	PC96 Series
HTC	PC991XX
HTC	PD051XX
HTC	PD06100
HTC	PD11 Series
HTC	PD15xxx
HTC	PD2610000
HTC	PD29xxx
HTC	PD42XXX
HTC	PD67100
HTC	PD98xxx(A9192)
HTC	PG05XXX
HTC	PG06XXX
HTC	PG321XX
HTC	PG32XXX
HTC	RHOD100 Series
HTC	RHOD50000 Series
HTC	TWIN10000 Series
HTC	WHIT10000 Series
HUAWEI	C8150
HUAWEI	C8150-1
HUAWEI	HUAWEI C8500
HUAWEI	HUAWEI C8600/ HUAWEI M860
HUAWEI	HUAWEI U8300/ U8300
HUAWEI	S31HW/ U8150-92/ HUAWEI U8150-92
HUAWEI	U8150-A
HUAWEI	U8150-D
HUAWEI	UM840
Inventec	T-101
iWOW	Libero
KT Tech	EV-S100
KT Tech	KM-S120
Kyocera	CLIP
Kyocera	Glide-M1400
Kyocera	K50
Kyocera	M2000
Kyocera	Mobile Phone 16 (E76)
Kyocera	S1310

Kyocera	S2300
Kyocera	S2410
Kyocera	SANYO SCP-3810
Kyocera	SCP-2700
Kyocera	SCP-8600
Kyocera	Torino
LG	BL20df/ BL20cf
LG	BL40/ BL40g/ BL40f
LG	BL40e
LG	BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/ BL20N
LG	GC900/ GC900F
LG	GC900e
LG	GC970/ GC970h
LG	GD510
LG	GD510N
LG	GD550
LG	GD550e
LG	GD570
LG	GD570AW, GD570AV
LG	GD880/ GC970
LG	GD880f, GD880g
LG	GD900/ GD900e
LG	GM210
LG	GM360i
LG	GM600
LG	GM730/ GM730f/ GM735/ GM730e
LG	GM750
LG	GM750h
LG	GM750Q
LG	GR700
LG	GS290
LG	GS390
LG	GS500
LG	GS500f for PCL
LG	GS500f, GS500g, GS500k, GS500v
LG	GS500gX
LG	GS505
LG	GT350
LG	GT350F
LG	GT350i
LG	GT360
LG	GT370
LG	GT400/ GT405
LG	GT500/ GT505
LG	GT550
LG	GT620
LG	GT950Q
LG	GU280, GU285, GU285f, GU285g
LG	GU280f
LG	GU282
LG	GU290/ GU290f
LG	GU290v

LG	GU295/ GU292
LG	GU295f, GU295g
LG	GU295g
LG	GU297 , GU297a
LG	GW300, LG900G
LG	GW300FD, GW305
LG	GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g
LG	GW525gX
LG	GW550
LG	GW550h
LG	GW820, GW825, GW825v
LG	GX500
LG	KC910, KC910Q, KC910Qa, KC910e, KC910i
LG	KM553
LG	KM555
LG	KM555e
LG	KM555R
LG	KM570
LG	KP500N
LG	KP501/ KP502/ KP550
LG	KP505
LG	KS365
LG	KT770, KT770f
LG	L-04C
LG	LG 3G Mobile Phone (GD910)
LG	LG 3G Mobile Phone (GT950)
LG	LG 3G Mobile Phone (LG- GT540/ GT540f/ GT540g)
LG	LG 3G Mobile phone (LG-C550 / LG-C550f)
LG	LG 3G Mobile Phone (LG-GB258)
LG	LG 3G Mobile Phone (LG-P350)
LG	LG 3G Mobile Phone(GM730E)
LG	LG 3G Mobile Phone(GW820)
LG	LG 3G Mobile Phone(KB770, KB775, KB775f)
LG	LG 3G Mobile Phone(LG-KU3800)
LG	LG 3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v, LG-T320k, LG-T320gv)
LG	LG CDMA Mobile Phone (LG-CX7100)
LG	LG CDMA Mobile Phone (LG-LG5500X for Koodo)
LG	LG CDMA Mobile Phone (LG-MN180)
LG	LG CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 / CM200 / BM200/ LW200/ MN200 / CX200B / CX200 / JN200)
LG	LG CDMA Mobile Phone (LG-VS910)
LG	LG CDMA Mobile Phone (VX7100)
LG	LG CDMA Mobile Phone (VX8575/ AX8575)
LG	LG CDMA Mobile Phone(LG LN510)
LG	LG CDMA Mobile Phone(LG- LN510)
LG	LG CDMA Mobile Phone(LG220C)
LG	LG CDMA Mobile Phone(LG-CX9200)
LG	LG CDMA Mobile Phone(LG-CX9600)
LG	LG CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700, LG700, CX700, MV700, MX700, MD700, VM700)
LG	LG GSM Mobile Phone (LG-C320i)
LG	LG GSM/ GPRS/ EDGE Mobile Phone (GM360)

LG	LG KM900, LG KM900e, LG KM900f, LG KM900g
LG	LG- LG265X
LG	LG TD-SCDMA Mobile Phone (GT910s)
LG	LG TD-SCDMA Mobile Phone(LG KT878)
LG	LG WCDMA Mobile Phone (LG-SU550)
LG	LG WCDMA Mobile Phone (LG-SU920, LG-KU9200)
LG	LG WCDMA Mobile Phone(LG-SU130)
LG	LG WCDMA Mobile Phone(LG-SU630)
LG	LG WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)
LG	LG230(CX230), LG231(CX231), LG231C(CX231C)
LG	LG370
LG	LG700V, CX700V
LG	LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v
LG	LG-AX265
LG	LG-AX265 [Not Approved by SIG]
LG	LG-AX8370
LG	LG-AX840
LG	LG-C320
LG	LG-C510/ C510
LG	LG-C570f
LG	LG-C570g
LG	LG-C710h/ LG-C710
LG	LG-C900
LG	LG-C900N, LG-C900k, LG-C900B
LG	LG-CX5500X
LG	LG-E500
LG	LG-E720, LG-E720b, LG-E720k
LG	LG-E900, LG-E900h
LG	LG-GB250
LG	LG-GD970
LG	LG-GM310/ LG-GM310f/ LG-GM310g
LG	LG-GW370
LG	LG-GW520/ LG-GW525/ GW525f/ GW525g
LG	LG-GW610
LG	LG-GW820, LG-GW825
LG	LG-JN240
LG	LG-JS750, LG-JS750g
LG	LG-KH3400
LG	LG-KH3400
LG	LG-KH3900
LG	LG-KH8000
LG	LG-KS720
LG	LG-KU2100, LG-SU210, LG-LU2100
LG	LG-KU2200
LG	LG-KU9300
LG	LG-KV700 (Lollipop2)
LG	LG-KV700T
LG	LG-KW730
LG	LG-LB4400
LG	LG-LG265T
LG	LG-LG8575/ LG-MX8575
LG	LG-LU2700
LG	LG-LU3000

LG	LG-LU4500
LG	LG-LU9400
LG	LG-LU9400W
LG	LG-LX295/ LG-LX290
LG	LG-MT375
LG	LG-P500/ LG-P509/ LG-P509TN
LG	LG-P500h
LG	LG-P501
LG	LG-P503
LG	LG-P505
LG	LG-P506
LG	LG-P920/ LG-P925/ LG-P929
LG	LG-P970
LG	LG-P990
LG	LG-SB210
LG	LG-SB260
LG	LG-SU310, LG-LU3100
LG	LG-SU370/ LG-KU3700/ LG-LU3700
LG	LG-SU410
LG	LG-SU420/ LG-KU4200
LG	LG-SU430/ LG-KU4300/ LG-LU4300
LG	LG-SU660
LG	LG-SU910/ LG-KU9100/ LG-LU9100
LG	LG-SU950/ KU9500
LG	LG-SU960, LG-KU9600
LG	LG-SV400
LG	LG-SV770
LG	LG-T325 , LG-T325f, LG-T325g
LG	LG-UN430
LG	LG-US760
LG	LG-UX310, AX310, MT310(MetroPCS), LP310, LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310, MD310
LG	LGVN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/ MN270/ TN270/ AN270/ VM270
LG	LG-VN530
LG	LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/ AS670
LG	LG-VS740/ US740/ MS740/ AS740
LG	LG-VS750
LG	LG-VS760
LG	LG-VS761
LG	LG-VX11000
LG	LG-VX8576
LG	LG-VX9200
LG	LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240
LG	LU2300
LG	LW375
LG	LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/ VN610/ AN610
LG	MT375
LG	New LG 3G Mobile Phone(GD710)
LG	New LG CDMA Mobile Phone(LG-LG290C)

LG	UX220
LG	UX370
LG	VER-01
LG	VN250
LG	VX5600
LG	VX8370
MediaTek	MediaTek BlueZ (2.1+EDR)
MediaTek	Mediatek WM6.5 (EDR2.0)
Motorola	A3300c
Motorola	A853
Motorola	A855
Motorola	A955
Motorola	Amphora-i897
Motorola	Athens-i9 R2
Motorola	Banfi-i856
Motorola	Bei Hai TD
Motorola	Blackstone-R2
Motorola	Brightwater
Motorola	Castle
Motorola	Cordova
Motorola	Creekside-i886
Motorola	CRUSH
Motorola	EWP3100
Motorola	Fairbanks
Motorola	Finch
Motorola	FR6070, FR6076
Motorola	FR6874
Motorola	Halo
Motorola	Heartland
Motorola	i296-Gallo
Motorola	i410(Nevadacity)
Motorola	i686-Brightwater-2
Motorola	i786w (Mantra)
Motorola	MB200 refresh
Motorola	MB300 Backflip refresh
Motorola	MB501 refresh
Motorola	MB502
Motorola	MB508
Motorola	MB511
Motorola	MB520
Motorola	MB525
Motorola	MB810
Motorola	ME811
Motorola	Milestone XT720
Motorola	Moto A3000
Motorola	Motosurf A3000
Motorola	Motosurf A3100
Motorola	MT716
Motorola	Muscardini
Motorola	Oaknoll
Motorola	Quailhurst iDEN-i786
Motorola	RIVAL (TELUS)
Motorola	Rush

Motorola	VE440
Motorola	VoWLAN Single Mode Smartphone
Motorola	W418G
Motorola	W766
Motorola	WX345
Motorola	WX404
Motorola	XT502
Motorola	XT610
Motorola	XT701
Motorola	XT702
Motorola	XT711
Motorola	XT720
Motorola	XT800
Motorola	XT800+
Motorola	XT800c
Motorola	XT800W
Motorola	XT806
NEC CASIO	KMP7N4Y1-2A
Nokia	2705
Nokia	6788
Nokia	7705
Nokia	2332c
Nokia	6788i
Nokia	C1-03
Nokia	C5-01
Nokia	Nokia 1006
Nokia	Nokia 2705
Nokia	Nokia 3208c
Nokia	Nokia 3720c-2
Nokia	Nokia 5132
Nokia	Nokia 5611
Nokia	Nokia 5730s-1
Nokia	Nokia 6303c
Nokia	Nokia 6316s, 6316s-1
Nokia	Nokia 6350-1b
Nokia	Nokia 6350-1d
Nokia	Nokia 6600i-1c
Nokia	Nokia 6700c
Nokia	Nokia 6700c-1
Nokia	Nokia 6750-1b
Nokia	Nokia 6750-1c
Nokia	Nokia 6760s-1
Nokia	Nokia 6790s-1b
Nokia	Nokia 6790s-1c
Nokia	Nokia 7205
Nokia	Nokia 7208
Nokia	Nokia 7208
Nokia	Nokia 7505 CDMA Mobile Phone
Nokia	Nokia 7705
Nokia	Nokia 8208
Nokia	Nokia E71x
Nokia	Nokia E75-1
Nokia	Nokia E75-2

Nokia	Vertu ASCENT X
Nokia	Vertu Constellation F
Nokia	Vertu Signature SC
Nokia	X3-01
Nokia	X5-00
Palm	P100EWW
Palm	P100UNA/ P100UEU
Palm	P101EWW
Palm	P101UNA, P101UEU
Palm	P120EWW
Palm	P121EWW
Palm	P121UNA, P121UEU
Palm	Treo Pro, T850EWW
Pantech	CDM8999**
Pantech	CDMA PT106 (IS06)
Pantech	IM-A600S
Pantech	IM-A630K (SP33K)
Pantech	IM-A630K (SP33K)
Pantech	IM-A650S
Pantech	IM-A690L
Pantech	IM-A690S
Pantech	IM-A710K
Pantech	MD Cube
Pantech	P2000
Pantech	P2020
Pantech	P6010
Pantech	P7000
Pantech	P7040
Pantech	P8000
Pantech	P9020
Pantech	P9050
Pantech	PIVOT **
Pantech	PIVOT/ TXT8030##
Pantech	Show(TXT8040, VZW-1026)
Pantech	TXT8035PP
Pantech	TXT8040##
Pantech	WP8990
Pharos	PTL117
Pharos	PTL127
RIM	BlackBerryR 8530 Smartphone
RIM	BlackBerryR 8910 Curve? Smartphone
RIM	BlackBerryR Bold? 9000
RIM	BlackBerryR Bold? 9650 Smartphone
RIM	BlackBerryR Bold? 9650 Smartphone
RIM	BlackBerryR Bold? 9700
RIM	BlackBerryR Bold? 9780 smartphone
RIM	BlackBerryR Curve? 8330
RIM	BlackBerryR Curve? 8350i
RIM	BlackBerryR Curve? 8520 Smartphone
RIM	BlackBerryR Curve? 8900
RIM	BlackBerryR Curve? 9300
RIM	BlackBerryR Curve? 9330 Smartphone
RIM	BlackBerryR Pearl? 8230

RIM	BlackBerryR Pearl? 9100 Smartphone
RIM	BlackBerryR Pearl? 9105 Smartphone
RIM	BlackBerryR Storm2? 9520
RIM	BlackBerryR Storm2? 9550
RIM	BlackBerryR Storm? 9500
RIM	BlackBerryR Storm? 9530
RIM	BlackBerryR Style? 9670 Smartphone
RIM	BlackBerryR Torch? 9800
RIM	BlackBerryR Tour? 9630 Smartphone
Samsung	C3050
Samsung	C3050
Samsung	C3110H
Samsung	C6625
Samsung	E3010
Samsung	GT- S8500
Samsung	GT-B2710
Samsung	GT-B2710D
Samsung	GT-B3210
Samsung	GT-B3310
Samsung	GT-B3310i
Samsung	GT-B3313i
Samsung	GT-B3410
Samsung	GT-B3410R
Samsung	GT-B3410W
Samsung	GT-B5210U
Samsung	GT-B5310
Samsung	GT-B5310B
Samsung	GT-B5310L
Samsung	GT-B5310R
Samsung	GT-B5310U
Samsung	GT-B6520
Samsung	GT-B6520L
Samsung	GT-B7300
Samsung	GT-B7300B
Samsung	GT-B7300C
Samsung	GT-B7320
Samsung	GT-B7320L
Samsung	GT-B7330
Samsung	GT-B7330B
Samsung	GT-B7330D
Samsung	GT-B7330R
Samsung	GT-B7350
Samsung	GT-B7350T
Samsung	GT-B7610
Samsung	GT-B7620
Samsung	GT-B7620U
Samsung	GT-C3010
Samsung	GT-C3013
Samsung	GT-C3050
Samsung	GT-C3050C
Samsung	GT-C3053
Samsung	GT-C3060
Samsung	GT-C3200

Samsung	GT-C3300
Samsung	GT-C3300D
Samsung	GT-C3300i
Samsung	GT-C3300K
Samsung	GT-C3303K
Samsung	GT-C3500
Samsung	GT-C3503
Samsung	GT-C3510
Samsung	GT-C3510T
Samsung	GT-C3518
Samsung	GT-C3530
Samsung	GT-C5180
Samsung	GT-C5510
Samsung	GT-C5510H
Samsung	GT-C5510U
Samsung	GT-E2330B
Samsung	GT-E2530
Samsung	GT-E2652
Samsung	GT-E2652W
Samsung	GT-E3210
Samsung	GT-E3210B
Samsung	GT-E3210L
Samsung	GT-I5500
Samsung	GT-I5500M
Samsung	GT-I5503T
Samsung	GT-I5508
Samsung	GT-I5510
Samsung	GT-I5510B
Samsung	GT-I5510L
Samsung	GT-I5510T
Samsung	GT-I5700
Samsung	GT-I5700
Samsung	GT-I5700L
Samsung	GT-I5700U
Samsung	GT-I5800
Samsung	GT-I5801
Samsung	GT-I6220
Samsung	GT-I6230
Samsung	GT-I6410
Samsung	GT-I6500U
Samsung	GT-I6500U
Samsung	GT-I7410
Samsung	GT-I7500U
Samsung	GT-I7680
Samsung	GT-I8000H
Samsung	GT-I8000L
Samsung	GT-I8000T
Samsung	GT-I8180C
Samsung	GT-I8320
Samsung	GT-I8330
Samsung	GT-I8520
Samsung	GT-I8910L
Samsung	GT-I8910U

Samsung	GT-I9000
Samsung	GT-I9000
Samsung	GT-I9000B
Samsung	GT-I9000L
Samsung	GT-I9000M
Samsung	GT-I9000M
Samsung	GT-I9000T
Samsung	GT-I9003
Samsung	GT-I9003
Samsung	GT-I9003L
Samsung	GT-I9003L
Samsung	GT-I9008
Samsung	GT-I9010
Samsung	GT-I9020
Samsung	GT-I9020A
Samsung	GT-I9020T
Samsung	GT-I9023
Samsung	GT-I9088
Samsung	GT-M2510C
Samsung	GT-M2513
Samsung	GT-M2520
Samsung	GT-M3710
Samsung	GT-M7500C
Samsung	GT-M7600B
Samsung	GT-M7600H
Samsung	GT-M7600L
Samsung	GT-M7603
Samsung	GT-M8910
Samsung	GT-M8910B
Samsung	GT-M8910U
Samsung	GT-P1000
Samsung	GT-P1000L
Samsung	GT-P1000N
Samsung	GT-P1000T
Samsung	GT-S3100
Samsung	GT-S3310i
Samsung	GT-S3350
Samsung	GT-S3353
Samsung	GT-S3370
Samsung	GT-S3370B
Samsung	GT-S3370C
Samsung	GT-S3370E
Samsung	GT-S3370L
Samsung	GT-S3500i
Samsung	GT-S3501C
Samsung	GT-S3550
Samsung	GT-S3600i
Samsung	GT-S3601C
Samsung	GT-S3650
Samsung	GT-S3650C
Samsung	GT-S3650W
Samsung	GT-S3653
Samsung	GT-S3653W

Samsung	GT-S5150
Samsung	GT-S5230
Samsung	GT-S5230C
Samsung	GT-S5230G
Samsung	GT-S5230N
Samsung	GT-S5233A
Samsung	GT-S5233S
Samsung	GT-S5233T
Samsung	GT-S5233W
Samsung	GT-S5250
Samsung	GT-S5260
Samsung	GT-S5330
Samsung	GT-S5333
Samsung	GT-S5350
Samsung	GT-S5350L
Samsung	GT-S5510
Samsung	GT-S5510T
Samsung	GT-S5520
Samsung	GT-S5530
Samsung	GT-S5560
Samsung	GT-S5560C
Samsung	GT-S5560i
Samsung	GT-S5570
Samsung	GT-S5570B
Samsung	GT-S5570L
Samsung	GT-S5580
Samsung	GT-S5600
Samsung	GT-S5600B
Samsung	GT-S5600H
Samsung	GT-S5600L
Samsung	GT-S5600T
Samsung	GT-S5600V
Samsung	GT-S5603
Samsung	GT-S5603T
Samsung	GT-S5608U
Samsung	GT-S5620
Samsung	GT-S5620B
Samsung	GT-S5620L
Samsung	GT-S5628
Samsung	GT-S5628i
Samsung	GT-S5670
Samsung	GT-S5670B
Samsung	GT-S5670L
Samsung	GT-S5750E
Samsung	GT-S5830
Samsung	GT-S5830B
Samsung	GT-S5830L
Samsung	GT-S5830T
Samsung	GT-S6700T
Samsung	GT-S6703T
Samsung	GT-S6888
Samsung	GT-S7070
Samsung	GT-S7070C

Samsung	GT-S7220U
Samsung	GT-S7230
Samsung	GT-S7230B
Samsung	GT-S7230E
Samsung	GT-S7230L
Samsung	GT-S7233E
Samsung	GT-S7350i
Samsung	GT-S7350U
Samsung	GT-S7510
Samsung	GT-S8000B
Samsung	GT-S8000C
Samsung	GT-S8000C
Samsung	GT-S8000H
Samsung	GT-S8000L
Samsung	GT-S8000U
Samsung	GT-S8500
Samsung	GT-S8500
Samsung	GT-S8500B
Samsung	GT-S8500C
Samsung	GT-S8500L
Samsung	GT-S8500M
Samsung	GT-S8500R
Samsung	GT-S8530
Samsung	GT-S8530B
Samsung	GT-S8530L
Samsung	Marcel Reloaded
Samsung	S3110C
Samsung	S3500C
Samsung	S7350B
Samsung	S7350C
Samsung	S7350L
Samsung	S8000
Samsung	S8300C
Samsung	S8300T
Samsung	S8300V
Samsung	Samsung GT-I5500B
Samsung	Samsung GT-I5500L
Samsung	Samsung GT-I5800L
Samsung	Samsung Mobile Phone (GT-M2510)
Samsung	Samsung Mobile Phone (SCH-R311)
Samsung	Samsung Mobile Phone (SCH-U350)
Samsung	Samsung Mobile Phone (SCH-U450)
Samsung	Samsung Mobile Phone (SCH-U960)
Samsung	Samsung Mobile Phone (SPH-M550)
Samsung	Samsung Mobile Phone (SPH-M560)
Samsung	Samsung Mobile Phone (SPH-M850)
Samsung	Samsung Mobile Phone(GT-I8000)
Samsung	Samsung Mobile Phone(I8910)
Samsung	Samsung Mobile Phone(M7600)
Samsung	Samsung Mobile Phone(SCH-R560)
Samsung	Samsung Mobile Phone(SCH-U430)
Samsung	Samsung Mobile Phone(SCH-U640)
Samsung	SC-01B

Samsung	SC-01C
Samsung	SC-02B
Samsung	SCH-F809
Samsung	SCH-F859
Samsung	SCH-I100
Samsung	SCH-i220
Samsung	SCH-i220(MPCS)
Samsung	SCH-i225
Samsung	SCH-i329
Samsung	SCH-I400
Samsung	SCH-I500
Samsung	SCH-I520
Samsung	SCH-I579
Samsung	SCH-I800
Samsung	SCH-i899
Samsung	SCH-I909
Samsung	SCH-i920
Samsung	SCH-M710
Samsung	SCH-M715
Samsung	SCH-M720
Samsung	SCH-R100
Samsung	SCH-R250
Samsung	SCH-R260
Samsung	SCH-R260
Samsung	SCH-R260
Samsung	SCH-R260
Samsung	SCH-R312
Samsung	SCH-R330
Samsung	SCH-R330
Samsung	SCH-R335
Samsung	SCH-R350
Samsung	SCH-R351
Samsung	SCH-R360
Samsung	SCH-R520
Samsung	SCH-R570
Samsung	SCH-R580
Samsung	SCH-R630
Samsung	SCH-R631
Samsung	SCH-R631 2Thumb
Samsung	SCH-R700
Samsung	SCH-R710
Samsung	SCH-R850
Samsung	SCH-R860
Samsung	SCH-R880
Samsung	SCH-R880
Samsung	SCH-R900
Samsung	SCH-R910
Samsung	SCH-R915
Samsung	SCH-U350
Samsung	SCH-U360
Samsung	SCH-U370
Samsung	SCH-U450
Samsung	SCH-U450

Samsung	SCH-U450(Verizon)
Samsung	SCH-U460
Samsung	SCH-U820
Samsung	SCH-W899
Samsung	SGH-C414
Samsung	SGH-C414Y
Samsung	SGH-I896
Samsung	SGH-I897
Samsung	SGH-I897
Samsung	SGH-i917
Samsung	SGH-I917R
Samsung	SGH-I997
Samsung	SGH-J600E
Samsung	SGH-T259
Samsung	SGH-T499
Samsung	SGH-T759
Samsung	SGH-T839
Samsung	SGH-T939
Samsung	SGH-T959
Samsung	SGH-T959
Samsung	SGH-T959D
Samsung	SGH-T959D
Samsung	SGH-T959D
Samsung	SGH-T959V
Samsung	SHC-Z120L
Samsung	SHW-A280K
Samsung	SHW-A280L
Samsung	SHW-A280S
Samsung	SHW-M100S
Samsung	SHW-M110S
Samsung	SHW-M110S
Samsung	SHW-M110S
Samsung	SHW-M120S
Samsung	SHW-M130K
Samsung	SHW-M130K
Samsung	SHW-M130L
Samsung	SHW-M130L
Samsung	SHW-M135K
Samsung	SHW-M135L
Samsung	SHW-M180K
Samsung	SHW-M180L
Samsung	SHW-M180S
Samsung	SHW-M180W
Samsung	SHW-M185S
Samsung	SHW-M190S
Samsung	SHW-M200K
Samsung	SHW-M200S
Samsung	SHW-M210S
Samsung	SPH-D700
Samsung	SPH-i350
Samsung	SPH-M260
Samsung	SPH-M330
Samsung	SPH-M340

Samsung	SPH-M350
Samsung	SPH-M360
Samsung	SPH-M380
Samsung	SPH-M560
Samsung	SPH-M570
Samsung	SPH-M575
Samsung	SPH-M7200
Samsung	SPH-M7350
Samsung	SPH-M8400
Samsung	SPH-M900
Samsung	SPH-M900
Samsung	SPH-M910
Samsung	SPH-P100
Samsung	SWD-S500
Samsung	X01SC
Sonim	Sonim XP1300-A-R1 (Type: P25B005AA)
Sonim	Sonim XP1300-E-R1 (Type: P24B005AA)
Sonim	Sonim XP3300-A-R1 (Type: P25C005AA)
Sonim	Sonim XP3300-E-R1 (Type: P24C005AA)
Sony Ericsson	Aino/ U10
Sony Ericsson	ASPEN
Sony Ericsson	C510, C510a
Sony Ericsson	C901, C901a
Sony Ericsson	C903, C903a
Sony Ericsson	Cedar?
Sony Ericsson	Elm
Sony Ericsson	F100i
Sony Ericsson	Hazel
Sony Ericsson	J105 (Naite?)
Sony Ericsson	Satio/ U1
Sony Ericsson	Sony Ericsson A8i
Sony Ericsson	T707, T707a
Sony Ericsson	T715
Sony Ericsson	TM717
Sony Ericsson	U10
Sony Ericsson	Vivaz?
Sony Ericsson	Vivaz? pro
Sony Ericsson	W508, W508a
Sony Ericsson	W518a
Sony Ericsson	W705, W705u, W705a
Sony Ericsson	W715
Sony Ericsson	W995, W995a
Sony Ericsson	Xperia Pureness/ X5
Sony Ericsson	Xperia X10
Sony Ericsson	Xperia? X10 mini (Rev 2)
Sony Ericsson	Xperia? X10 mini pro (Rev2)
Sony Ericsson	Xperia? X8
Sony Ericsson	Yari
Sony Ericsson	Zylo?
ZTE	003Z
ZTE	a5
ZTE	Android Edition Starnaute
ZTE	BJK1903

ZTE	F160
ZTE	F870
ZTE	F870E
ZTE	F930
ZTE	F950
ZTE	F951
ZTE	F951E
ZTE	Jack 3G
ZTE	San Francisco
ZTE	T870
ZTE	T930
ZTE	Tactile internet 2
ZTE	Venus
ZTE	Vodafone 945
ZTE	XCD35
ZTE	ZTE F870
ZTE	ZTE F951
ZTE	ZTE F952 UM KP
ZTE	ZTE-1001
ZTE	ZTE-BLADE
ZTE	ZTE-C F350
ZTE	ZTE-U X990
ZTE	ZTE-U X991