


## Quick start guide for model DS3111-2

### Telephone base installation

We recommend that you install the telephone base away from any electronic equipment and appliances such as personal computers, computer routers, television sets, microwave ovens or refrigerators. Avoid excessive heat, cold, dust or moisture. When a location is selected, install the telephone base and the charger as shown below. Make sure that the electrical outlet is not controlled by a wall switch.




### Handset battery installation

Install the handset battery by following these steps:

- Align the two holes of the battery plug with the socket pins in the handset battery compartment, matching the red and black wires to the color-coded label.
- Place the battery in the compartment with the wires in the **lower right corner**.
- Position the battery compartment cover and slide it towards the unit until it clicks into place.

For optimal performance, we recommend that you charge the handset for 16 hours. You can keep the battery charged by returning the handset to the telephone base after each use. When the battery power is fully depleted, a full recharge takes about 16 hours.



#### NOTE:

You must program your voicemail buttons before you can access all of the functions available with your voicemail.

### Voicemail setup

This feature allows you to use the **VOICEMAIL**, **PLAY**, **SKIP** and **ERASE** buttons to access your voicemail (a subscription service available from your local telephone company for a fee). Before completing these steps, be sure to have your access number and password to access your voicemail available. You will also need the key sequence to play, skip and delete your messages. Contact your local telephone company for more information about voicemail service.

To program the **ACCESS NUMBER** button:

- Press **MENU/SELECT** from the idle mode.
- Press **▲** or **▼** to select **VOICEMAIL SETUP**, then press **MENU/SELECT**.
- Press **▲** or **▼** to select **ACCESS NUMBER**, then press **MENU/SELECT**.
- Use the dial pad to enter the access number. Press **MUTE/REMOVE** to delete characters if necessary.
- Press **MENU/SELECT**. You'll hear a confirmation tone.

To program the **PASSWORD**, **PLAY**, **SKIP** and **ERASE** buttons, follow the above steps.

To program a pause:

- Press **MENU/SELECT** from the idle mode.
- Press **▲** or **▼** to select **VOICEMAIL SETUP** then press **MENU/SELECT** twice.
- The blinking cursor should be at the end of your access number. Press **and hold** the **REDIAL/PAUSE** button until a **P** appears.
- Press **MENU/SELECT**. You'll hear a confirmation tone.


To reset all codes:

- Press **MENU/SELECT** from the idle mode.
- Press **▲** or **▼** to select **VOICEMAIL SETUP** then press **MENU/SELECT**.
- Press **▲** or **▼** to select **RESET ALL CODES**, then press **MENU/SELECT**.
- The screen displays **RESET CODES?**
- Press **MENU/SELECT**. You'll hear a confirmation tone.

### Make, receive and end calls

#### Make a call

- Press **TALK/FLASH** or **OFF** to ensure there is a dial tone, then dial the telephone number.




-OR-

- Dial the number (press **MUTE/REMOVE** to make corrections; **press and hold REDIAL/PAUSE** to insert a dialing pause).
- Press **TALK/FLASH** or **OFF** to use the speakerphone.

#### Receive a call

- Press **TALK/FLASH**, **OFF** or any dialing keys (**0-9**, **\*** or **#**) to answer an incoming call.



#### End a call

- Press **OFF/CLEAR** or put the handset back in the telephone base or charger.

#### NOTES:

- Use only the power adapters and batteries supplied with your VTech telephone.
- For complete feature instructions, please refer to your user's manual.

### IMPORTANT!

If your product is not working properly:

- Refer to the **Troubleshooting** section of the user's manual.
- Visit our website at [www.vtechphones.com](http://www.vtechphones.com). In Canada, go to [www.vtechcanada.com](http://www.vtechcanada.com).
- Call our customer service at 1 (800) 595-9511. In Canada, call 1 (800) 267-7377.